



PROVEN STRENGTH  
**Tramanco**  
Since 1975

| Family   | Model           | Lift Weight<br>kg | FTG<br>mm | Lift Capacity<br>kg | Volts<br>V | Clear Inside Platform Width<br>mm | Clear Inside Platform Length<br>mm | Overall Loader Height<br>mm | Overall Extension of Arc, from stowed position to Maximum Height<br>mm | Overall Loader Width<br>mm | Overall Dimension of outside lift arms Width<br>mm | Overall Loader Depth At handrail height<br>mm | Overall Loader Depth At base with Cover when folded<br>mm | Base Plate length<br>mm | Base Plate Width<br>mm | Kick-out is measured from front of base plate edge to the closest point, for the platform has been lowered down 100mm from floor level<br>mm | Kick-out is measured from the front of base plate edge, to the Rotating Pivot side arm or saddle, at floor level<br>mm | Kick-out is measured from, front of base plate edge to Rotating Pivot side arm or saddle at 100mm down<br>mm |
|----------|-----------------|-------------------|-----------|---------------------|------------|-----------------------------------|------------------------------------|-----------------------------|--|----------------------------|--|---|---|-------------------------|------------------------|--|--|--|
| E-Series | ADEC08S86132LTC | 143               | 800       | 400kg               | 12V        | 860                               | 1320                               | 1420                        | + 10   | 1215                       | 1090   | 450   | 430   | 1112                    | 325                    | 362  | 410  | 415  |

*\*All measurements are to be used as a guide as slight variations may occur between all units\**

**Quick Facts**

- One piece full expanded mesh platform
- 400kg lifting capacity
- Illuminated platform
- Easy access integrated manual back-up pump and handle
- Durable hand-held control unit
- Dual handles to assist with standee and wheelchair users
- Lift-Tite system automatically secures the platform when in transit
- Durable ripple black finish
- Side or rear door application
- Electrohydraulic power up/gravity down operation
- Mechanically operated out-board barrier
- Equipped with adjustable anti-rattle features to suppress noise during transit
- Tramanco colours
- Safety yellow automatic mechanical in-board