

BraunAbility® E-Series Vertical Split Platform ADEC08V86132LTC



Family	Model	Lift Weight kg	FTG mm	Lift Capacity kg	Volts V	Clear Inside Platform Width mm	Clear Inside Platform Length mm	Overall Loader Height mm	Overall Extension of Arc, from stowed position to Maximum Height mm	Overall Loader Width mm	Overall Dimension of outside lift arms Width mm	Overall Loader Depth At handrail height mm	Overall Loader Depth At base with Cover when folded mm	Base Plate length mm	Base Plate Width mm	Kick-out is measured from front of base plate edge to the closest point, for the platform has been lowered down 100mm from floor level mm	Kick-out is measured from the front of base plate edge, to the Rotating Pivot side arm or saddle, at floor level mm	Kick-out is measured from, front of base plate edge to Rotating Pivot side arm or saddle at 100mm down mm
E-Series	ADEC08V86132LTC	149	800	400kg	12V	860	1320	1420	+ 35	1215	1090	550	430	1112	325	362	410	415

All measurements are to be used as a guide as slight variations may occur between all units

Quick Facts

- Two piece split expanded mesh platform
- 400kg lifting capacity
- Illuminated platform
- Easy access integrated manual back-up pump and handle
- Durable hand-held control unit
- Dual handles to assist with standee and wheelchair users
- Lift-Tite system automatically secures the platform when in transit
- Durable ripple black finish
- Side or rear door application
- Electrohydraulic power up/gravity down operation
- Mechanically operated out-board barrier
- Equipped with adjustable anti-rattle features to suppress noise during transit
- Tramanco colours
- Safety yellow automatic mechanical in-board barrier.